

“Simple Extension” Installation

Having help with this is recommended if you have never laid your vision down.

1. Lay the vision down on the right side using tip over protectors. May be good idea to lay some towels down where tip over will come in contact with ground to prevent scratching them.
2. The rubber pad has two rivets. Use a ¼” diameter drill bit to remove the flared section. Drill slowly and pulse the drill to keep from spinning the rivets. The rivets may have swelled in the mounting holes when the factory installed them. Use a punch to drive them out. Have your helper brace the kickstand while you do this.
3. Bolt the extension to the kickstand with the supplied stainless hardware.
4. Make sure the kickstand is in the down position and stand the bike back up.

The bottom of the extension is meant to be a wear surface. This gives the stand some grip on the parking surface. You can contact us for information at our email peterpeterllc@aol.com

Enjoy and Ride Safe.

Thank You!